

# Contents

<b>Introduction</b>	<b>3</b>	<b>Modifications</b>	<b>29</b>
<b>About This Manual</b>	<b>4</b>	Modification 1 - Insert Point Post/Pre EQ	29
Terminology	4	Modification 2 - Installing Additional Modules	29
Quickstart	4	<b>Block Diagrams</b>	<b>30</b>
<b>Installation</b>	<b>5</b>	Channel & Input Block Diagram	30
<b>Health &amp; Safety</b>	<b>5</b>	Group Amps	31
<b>Connections</b>	<b>5</b>	Stereo Mix & Outputs	32
Master Section Rear Panel	6	CR Monitor	33
Channel Bin Rear Panel	8	AUX Headphone & Stereo Returns	34
<b>Operation</b>	<b>9</b>	Ancillary	35
Powering Up	9	<b>Dimensions</b>	<b>36</b>
The Power Supply and Soft Start	9	32 Channel Frame	36
Retro and Modern Circuitry	10	24 Channel Frame	36
<b>The 2081 Module</b>	<b>12</b>	16 Channel Frame	36
<b>Meterbridge</b>	<b>12</b>	<b>Recall Sheets</b>	<b>37</b>
<b>Input Module</b>	<b>13</b>	<b>Wiring Diagrams</b>	<b>40</b>
<b>Auxiliaries</b>	<b>13</b>	XLR Connectors	40
<b>2081 EQ</b>	<b>14</b>	1/4" TRS & TS Connectors	40
<b>Monitor path, Channel Output &amp; Retro</b>	<b>14</b>	DB25 Connectors	40
<b>Channel Path Fader</b>	<b>15</b>	<b>Master Section Rear Panel</b>	<b>41</b>
<b>Master Section</b>	<b>16</b>	7.1 Inputs	41
<b>Metering</b>	<b>17</b>	Surround Spk (Alt2)	41
<b>2254 Compressor</b>	<b>18</b>	Reverb (Stereo) Returns	42
2254 Compressor Meters	18	Speakers	42
2254 Controls	18	Aux Sends	42
Limiter	19	SLS, Red Light, TB, Listen	42
<b>Assign Section</b>	<b>19</b>	Headphones	43
Channel Routing	19	Mix Insert, 2 Trk 1,2	43
Channel Functions	19	Mix Outs & 2254	43
Scenes	20	Group Outputs/Insert Sends	43
Custom User Features	20	Stem Outputs	44
<b>Oscillator &amp; SLS</b>	<b>21</b>	DAW/Ins Return	44
Oscillator	21	<b>Channel Bin Rear Panel</b>	<b>45</b>
SLS	21	Channel Insert Sends	45
<b>Group Send/Returns</b>	<b>22</b>	Channel Insert Returns	45
<b>Reverb Returns</b>	<b>23</b>	DAW Inputs	45
<b>Auxiliary Master Section</b>	<b>23</b>	Line Inputs	45
<b>Headphone Sends</b>	<b>23</b>	Direct Outputs	46
<b>Channel Meters/Master Meters</b>	<b>24</b>	<b>Glossary</b>	<b>47</b>
Channel Meter Controls	24	Amplifying Stages	47
Master Meter Controls	24	Channel Bin	47
<b>Console/Channel Modes</b>	<b>24</b>	Current Summing	47
<b>Control Room</b>	<b>26</b>	Modern Output Stage	47
Control Room Volume and Controls	26	Retro Output Stage	47
Monitor Source	26	Stem Outputs	47
Control Room Headphones	27	Voltage Summing	47
Solo	27	<b>Credits</b>	<b>48</b>
Talkback and Listen Mic	27		
<b>Faders</b>	<b>28</b>		